

Electronic Tally Counter Model AT1 and AST2

Operating instructions

- (1) Press On/Off/Reset button to power ON the Unit.
- (2) To reset/off counter, press the On/Off/Reset button for 3 seconds to reset to 0, And press 3seconds more, the unit will be turn off.
- (3) To count: Press the count button "+" and "-", to Add and Subtract.
- (4) To switch the Beeper sound at any time: Press "+" button 3 seconds, to switch the beeper sound, LCD show "s"(Sound) and "m"(Mute).
- (5) To turn on the blue backlight: Press On/Off/Reset button 2 times within 1 second. The blue backlight will automatically turn off after 3 seconds.
- (6) LCD and Counts: The LCD will automatically turn off if there is no action in 30min. The same counted number will be activated on the LCD when you press On/Off/Reset button.
- (7) To take out the button cell in case the counter do not work, and set the button cell back after 2 seconds.

Battery information

- (1) Battery type:G13-A 1.5V Button cell
- (2) Observe polarity(+/-) during replacement
- (3) Do not over lighten the screws

Safety

Retain this information for future reference

This product contains glass and may cause injury if broken

This is not a toy hence is not suitable for children under 3 years of age